

## SŁUCHAWKI LENOVO THINKPLUS LP 75 CZARNE



Lenovo thinkplus LivePods LP75

Instrukcja użytkownika

- (1) Nie próbuj demontować urządzenia i wymieniać żadnej części, chyba że w instrukcji opisano sposób obsługi.
- (2) Nie wystawiaj urządzenia na działanie cieczy, wilgoci ani wilgoci, ponieważ nie jest to produkt wodoodporny.
- (3) Odłącz urządzenie od urządzenia BT i przenieś je w bezpieczne miejsce, jeśli płyn dostanie się do wnętrza urządzenia.
- (4) Nie montuj ani nie demontuj urządzenia, aby uniknąć porażenia prądem, jeśli masz wodę na rękach.
- (5) Nie wystawiaj urządzenia na działanie bardzo wysokich temperatur ani nie wyrzucaj go urządzenia znajdującego się w ogniu, gdyż grozi to eksplozją.

(6) Nie umieszczaj urządzenia w środowisku zakłóceń elektromagnetycznych, aby uniknąć nieprawidłowego działania

Lista rzeczy do spakowania

Słuchawki X 2

Instrukcja obsługi X1

Etui ładujące X1

Kabel ładujący X1

Specyfikacja produktu

Wersja BT: V5.3 Zasięg roboczy: >10M

Bateria słuchawek: 40 mAh

Czas odtwarzania: około 6 godzin (słuchawki) Czas ładowania: około 15 godzin (słuchawki) Wejście znamionowe: 5 V 35 mA

Specyfikacja etui ładującego

Bateria w obudowie: 300 mAh

Czas ładowania: około 1,5 godziny

Wejście znamionowe: 5 V

250mA

(Wszystkie informacje techniczne zależą od rzeczywistej wydajności)

Aby naładować sprawę

Podłącz kabel typu C do zasilacza SV, a drugi koniec do portu ładowania etui ładującego.

Dwie słuchawki zostają sparowane z urządzeniami BT: Obie kontrolki słuchawek dousznych zgasną

Wskaźnik Niski poziom naładowania baterii: Wskaźnik LED słuchawek będzie migać na biało

szybko kolorować.

Instrukcja obsługi

1. Włącz:

Metoda 1: Otwórz obudowę, słuchawka włączy się automatycznie. Metoda 2 Naciśnij i przytrzymaj przycisk M na słuchawce przez 3 sekundy, aby włączyć słuchawki.

2. Wyłącz

Metoda 1: Włóż słuchawki bezpośrednio do etui ładującego i zamknij obudowę, aby je wyłączyć.

Metoda 2: Naciśnij i przytrzymaj przycisk MF na słuchawkach, aby wyłączyć słuchawki.

3. Parowanie z urządzeniem BT

Krok 1: Otwórz obudowę, słuchawka włączy się automatycznie Krok 2: Aktywuj funkcję BT na swoim urządzeniu mobilnym, wyszukaj i wybierz „thinkplus-LP75” z listy dostępnych urządzeń BT.

(Pojedyncza słuchawka również działa)

podręcznik

Proszę uważnie przeczytać wszystkie instrukcje i zachować do wykorzystania w przyszłości

Lenovo

Wkładki douszne (M) X 2 wkładki douszne (L) X2

Schematyczny opis produktu

Stan wskaźnika LED

Dioda LED słuchawek

Zasilanie włączone: Obie strony Wskaźnik LED świecą na zielono przez 1 sekundę

Wyłączenie zasilania Obie strony Wskaźnik LED miga na biało 3 razy, a następnie gaśnie

Dwie słuchawki zostają ze sobą sparowane.

Wskaźnik Przed sparowaniem dwóch słuchawek kontrolka miga powoli na przemian na biało i zielono. Po sparowaniu dwóch słuchawek kontrolka słuchawki głównej miga szybko na zmianę na biało i zielono, a kontrolka słuchawki dodatkowej gaśnie.

Obsługa przycisku sterowania dotykowego

Tryb odtwarzania muzyki

Działa lewa/prawa słuchawka

Zwiększanie głośności: Naciśnij krótko przycisk M na prawej słuchawce, aby zwiększyć głośność

Zmniejszanie głośności: Naciśnij krótko przycisk MF na lewej słuchawce, aby zmniejszyć głośność

Pauza/odtworzenie: naciśnij krótko przycisk MP jednej słuchawki 2 razy spowoduje lub odtworzy muzykę

Poprzedni utwór: Krótkie naciśnięcie przycisku MF na lewej słuchawce 3 razy spowoduje powrót do poprzedniego utworu

stojak na prawą słuchawkę

Funkcja głośnomówiąca

Działa lewa/prawa słuchawka

Krótko naciśnij przycisk Mr na dowolnej słuchawce 2 razy, aby odebrać połączenie przychodzące

Zakończenie połączenia: Po rozmowie telefonicznej naciśnij krótko 2 razy przycisk MP dowolnej słuchawki.

Odrzucanie połączenia przychodzącego: Naciśnij przycisk MF dowolnej słuchawki na 2 sekundy i zwolnij

Aktywuj funkcję asystenta głosowego (urządzenia inteligentne obsługują funkcję asystenta głosowego)


Działa lewa/prawa słuchawka

Resetowanie

Aktywuj funkcję asystenta głosowego: dotknij i przytrzymaj jedną z nich naciśnij przycisk funkcji mus na 2 sekundy, po czym usłyszysz kamień

Po włączeniu słuchawki upewnij się, że nie łączy się ona z żadnym urządzeniem BT i kliknij 5 razy przycisk MF, aby wyczyścić zapis parowania, a następnie wyłącz słuchawki.

Lenovo thinkplus LivePods LP75



**Manual**  
Please read all instructions carefully and retain for future use

**Lenovo**


**Usage Instruction**

(1) Don't attempt to disassemble the unit and change any part, except there is operation method mentioned in the manual.  
(2) Don't expose the unit to liquid, moisture or humidity, since it is not a waterproof product.  
(3) Disconnect the unit with your BT device and move it to the safe area if the liquid get inside the unit.  
(4) Don't assemble or disassemble the unit to avoid electric shock, if there is water on your hands.  
(5) Don't expose the unit to extremely high temperature or dispose of the unit in fire as it will result in an explosion.  
(6) Don't place the unit in an electromagnetic interference environment to avoid malfunction.

**Packing list**

	Earphone X 2		Charging case X 1
	User manual X 1		Charging cable X 1
	Earbuds(S) X 2 Earbuds(M) X 2 Earbuds(L) X 2		

**Product schematic description**



**Product specification**


BT Version: V5.3  
Working range: >10M  
Earphone battery: 40mAh  
Playing time : about 6 hours ( Earphone )  
Charging time : about 1.5 hour ( Earphone )  
Rated input: 5V = 35mA

**Charging case specification**

Case Battery: 300mAh  
Charging Time : about 1.5 hours  
Rated input : 5V = 250mA  
(All technical information is subject to actual performance)

**To Charge the case**

Connect the Type-C cable to the 5V power adaptor, and another end to the charging port of the Charging Case.



Input: 5V=35mA (Earphone)    Input: 5V=250mA (Case)

**LED Indicator Status**

**Earbuds LED Indicator**

- Power on: Both sides LED Indicator keep in green color for 1 second then go off.
- Power off: Both sides LED indicator flash in white color for 3 times then go off.
- Two earphone get paired each other:
- Before two earphone get paired, the indicator light flashes slowly alternately between white and green. After two earphone get paired, the master earphone indicator light flashes quickly alternately between white and green, and the sub earphone indicator light goes off.

**Earbuds LED Indicator**


- Two earphone get paired with BT devices: Both of the indicator lights go off.
- Low battery: Earphone LED Indicator will flash in white color quickly.

**Operating Instruction**

**1. Turn on:**  
Method 1: Open the case, the earphone will turn on automatically.  
Method 2: Long touch the MF button of the earphone for 3s to turn on the earphone.

**2. Turn off:**  
Method 1: Put the earphones into the charging case directly and close the case to turn off.  
Method 2: Long touch the MF button of the earphones for 3s to turn off the earphones.

**3. Pairing to the BT device**  
Step 1: Open the case, the earphone will turn on automatically.  
Step 2: Activate the BT function on your mobile device, search and select the "Lenovo thinkplus-LP75" from the list of available BT devices. (Single earphone is workable too)



## Touch control button operating

### Music playing mode

#### Left/Right earphone operating



- Increase Volume: Short press the MF button of right Earphone to increase the volume
- Decrease Volume: Short press the MF button of left Earphone to decrease the volume
- Pause/Play: Short press the MF button of one Earphone for 2 times will pause or play the music
- Previous track: Short press the MF button of left earphone 3 times will return you to the previous track
- Next track: Short press the MF button of right earphone 3 times will take you to the next track

### Hands free function

#### Left/Right earphone operating



- Short press the MF button of any earphone 2 times to answer an incoming call.
- End call: After your phone conversation, short press the MF button of any earphone 2 times.
- Reject incoming Call: Press the MF button of any earphone for 2 seconds and release

### Active the voice assistant function (the smart devices support voice assistant function)

#### Left/Right earphone operating



- Active the voice assistant function: touch and hold either of the multi-function button for 2 seconds, then you will hear the "tone".

### Reset

When you turn on the earphone, make sure it does not connect to any BT device, and click the MF button 5 times to clear the pairing record, then turn off the earphone.

## Name and content of hazardous substances in products

### Name and content of hazardous substances in products

Part Name	Harmful materials					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364.  
 ○ : Indicates that the content of the hazardous substance in all homogeneous materials of the part is in Below the limit requirements specified in GB/T 26572.  
 X : Indicates that the content of the hazardous substance in at least one of the homogeneous materials of the part exceeds the limit requirements specified in GB/T 26572.  
 The parts marked with "X" on the form are all harmful due to the limitations of global technological development. Substitution of substances.

Printed circuit board components\*: including printed circuit boards and their parts, electronic components, etc. Depending on the product model, the product you purchased may not contain all the above components



Electronic and electrical products sold in the People's Republic of China must mark this Logo, the number in the logo represents the product under normal use Environmental protection use period.

## Warranty statement

### Disclaimer

This user manual does not have any form of guarantee, position expression or other implication. The mentioned products, specifications and information are for reference only, and the content will also be updated on the webpage at any time, without additional line notification.

### Warranty statement:

The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired free; if the manufacturer confirms

that it cannot be repaired, free replacement; repaired or replaced product, Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchase date by sale. The ticket date shall prevail; if the purchase date cannot be determined, the warranty period shall be 13 Months calculation.

If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice. The above guarantee does not apply to the following situations:

1. The validity period of the three packs is exceeded;
2. Alteration of the warranty card and product code does not match the product body;
3. Causes caused by misuse, abuse or improper transportation, use, maintenance or storage/impairment or damaged;
4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accident bad;
5. The zipper and buckle are damaged due to excessive force;
6. Disconnection or tearing caused by excessive load;
7. Any damage caused by sharp objects;
8. Products with signs of burning or water immersion;
9. Damage caused by unauthorized disassembly;
10. Aging, discoloration, abrasion, rupture and other losses occurred during normal use of the product.
11. If the original identification label of the product is changed or damaged, this guarantee will become invalid. The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should Check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China. Nothing in this document affects consumer rights that cannot be excluded or restricted under the law profit.

After-sales service Email: frank@szeysan.cn

Service supervision hotline: 400-812-0102

"Lenovo", "thinkplus" belongs to affiliated enterprises of Lenovo Group.  
 Mentioned other trademarks, company names, products or services name may be a trademark of affiliated enterprises of Lenovo Group or another company.  
 Copyright © 2022 Lenovo Group and its licensors. All rights reserved.