
RESIN FILTER

Version 1.0

Shortdescription

Filter cured resin particles that could damage the FEP film.

Description

RESIN FILTER are paper funnel with integrated 125µm mesh to filter cured particles from resin. Resin should be filtered

- after a failed 3D print
- if particles are visible inside the resin tank
- if the resin is changed

Application

for removing cured resin particle

Wear gloves when handling resin. If available, place Resin bottle on a silicone mat and use a PP funnel to stable the filter. Pour the resin slowly from the resin tank of the 3D printer through the filter into the bottle.

Disposal of RESIN FILTER

To dispose of used resin filter let the resin cure under UV light. Dispose of fully cured resin filter is possible through household waste.